

SMART Board Buttons

Buttons on the Front of Board



1. Home Button – Will return you to the SMART Board IQ Home page from any screen
2. Input Button – Bring up a screen that allows you to choose what input you would like to display on the SMART Board
3. Blind Button – Turns the whole screen gray, quickly hiding what was on it
4. Pause Button – Pauses/freezes what you what you have on your computer
5. Volume Down Button – Turns volume of SMART board speakers down (independent from the volume controls on the computer)
6. Volume Up Button – Turns volume of SMART board speakers up (independent from the volume controls on the computer)
7. Power Button – Turns the SMART Board Screen off

Buttons of the Remote

1. Power Button – Turns the SMART Board Screen off
2. Home Button – Will return you to the SMART Board IQ Home page
3. Control Pad and OK Button – Allow you to navigate and select options within the SMART Board IQ
4. Back Button – Goes back to the previous page in the SMART Board IQ
5. Setting Button – Launched the SMART Board Settings
6. Input Button – Bring up a screen that allows you to choose what input you would like to display on the SMART Board
7. Screen Mirroring Button – Launches SMART Screen Mirroring App
8. Pause Button – Pauses/freezes what you what you have on your computer
9. Blind Button – Turns the whole screen gray, quickly hiding what was on it
10. Volume Down Button – Turns volume of SMART board speakers down
11. Mute Button – Mutes the volume on the SMART Board
12. Volume Up Button – Turns volume of SMART board speakers up



Master Power Switch

75 in. Boards

Switch is located on the rear of the board, and you can find it by reaching underneath the right-hand speaker.



65 in. Boards

Switch is located on the right side of the board at the bottom.

